



Cabinets should be attached to wood framed walls by screwing through the interior back panel into wall studs or blocking. Fasteners for wood framed walls are provided. The fasteners for other wall types are not provided.

Adjacent cabinets and components should be assembled by fastening through the interior panels with the screws or bolts provided. Tighten securely.

**Quantity -**

**Finish Schedule**

Face Color -  
Top Color -  
Toe Color -  
Pulls -  
Interior -  
Other (Specify) -

**Installation Notes:**

1. All hardware needed for assembly is included.
2. Large items are preassembled at the factory to ensure proper alignment. Items are then disassembled into manageable sections for shipping purposes and ease of reassembly.
3. Shipping cleats need to be removed before installation. These cleats are installed to prevent damage.

**collins** Collins Manufacturing  
809 E 20th Street  
Cookeville TN 38501

Title: **QSEp Tower Shampoo Assistant**

Size: # **429-18** Drawn By:

Date: **08/23/04** Sheet #: **4**