

Shampoo Fixture

603 BACKFLOW PREVENTER

603 BACKFLOW PREVENTER INSTALLATION INSTRUCTIONS IMPORTANT!

- a) The device shall be installed in accordance with the requirements of the local plumbing code.

CAUTION: In some older municipal water systems, there may be rust, sand and other debris which could block the backflow preventer and reduce water flow. Check with your plumber regarding the need to install a filter on the incoming water line.

NOTE: Conformance with local codes is the responsibility of the owner and/or the installer!

- b) The device shall be installed downstream of the last valve.
1. Before installing your new Belvedere shampoo bowl, we recommend that you first install the plumbing fixtures to the bowl. Install fixtures according to the instructions packed with them.



603 BACKFLOW PREVENTER

2. Attach the backflow preventer to the fixture tailpiece. Do not overtighten. Place the end of the spray hose with the brass connector through the hole in the hose receiver. Attach the spray hose connector to the backflow preventer.

