







- 1 Pull CJ MAX Cap from the pedicure bowl
- 2 Remove Banana Plug by simply pulling it from the cap
- 3 Turn the CJ MAX Cap cover counter-clockwise (below the silver tab and banana plug hole are arrows)
- 4 Remove magnetic puck and turn the CJ MAX Cap heavy base upside down on a flat, sturdy surface

5  Using a solid, sturdy object (such as a pen or screwdriver) push the bushing out from the cap's base as per the accompanying picture. Always use care and caution when using any kind of tool or instrument.

6  Insert the new bushing so that the narrow end of the bushing is pushed through to the back of the back plate, leaving the flat, wide end of the bushing on the top portion of the back plate (see image) Gently tap the bushing to secure it to the base

7  Reassemble the Clean Jet MAX Cap  
Place magnetic puck back into heavy base  
Replace the cap cover by placing the banana plug hole on the cover slightly to the left of the banana plug hole on the base.  
Turn the cap cover clockwise so the banana plug holes are aligned.  
Insert the banana plug

8  Place CJ MAX Cap back onto spa base so that the outer tab is pointed upward