

ASSEMBLY INSTRUCTIONS

1. Press end cap over the front end of each leg.
2. Attach right dryer leg to the side of the dryer with the three (3) #8 x 1" screws. (NOTE: The countersink should be to the outside of the leg.)
3. Slide axle through leg (as shown in the drawing). Slip wheel over axle and secure with 5/16 - 18 acorn locknut.
4. Attach left dryer leg by repeating STEP 2. Slide the axle through the hole before tightening screws.
5. Install second wheel on left dryer leg with acorn nut as in STEP 3. Secure both acorn nuts securely.
6. Stand dryer upright and tighten all screws securely. Make sure that dryer stands level before final tightening.
7. Install dryer handle on dryer cabinet with four (4) #10 x 1/2" screws.

