


When attaching mirror frame to wall make sure to stay within the inside 2" with screws. The outer 2" will be visible. Note: top frame is marked with a "T".

Attach bottom edge of bottom mirror frame 19 1/2" above floor. The edge of the frame should be 4" from the side of tower unit. Slide the side mirror frames in place by lowering the attached mending plate into the notch in bottom frame. Make sure the predrilled holes for the shelf clamps are toward the bottom.

The use of a construction adhesive is suggested behind side frame pieces. Slide top frame over the mending plates and secure to wall. Attach the supplied mirror clips to frame using the pre-drilled holes. Put mirror in place. Attach shelf clamps and shelf.

Finish Schedule - J05

Face Color - Black
 Top Color - Black
 Toe Color -
 Reveal / Accent Color - Black
 Hardware -
 Interior - Black
 Other (Specify) - N/A

 Collins Manufacturing 2000 Bowser Road Cookeville, TN 38506		Title: J05 Java Mirror Assembly	
		Size: NTS	Drawing Number:
Date:		Sheet	