

AUTO FILL FEATURE - set level

- Turn the adjuster screw anti-clockwise as far as it will go.
 - Lift the faucet handle up to prime the water.
 - Press the 'J' button.
 - Water will start to fill the bowl.
 - When water has reached the level you require, turn the faucet off to stop the water.
 - Jets will come on.
 - **SLOWLY** turn the adjuster screw clockwise until the light (found on the side of the unit) comes on.
 - Water level is now set at this height for future fills.
 - **Please note:** Water will rise when customer's feet are lowered into the bowl.
-
- To test, press the 'J' button which will turn off the Auto Fill Feature, open the drain and release the water.
 - Follow the steps as shown in the Auto Fill Feature instructions.