


HAIR DRYER



I. Functions :

The product allows automatic temperature control, even and soft wind. These contribute to achieve better outcome for warming evening hairstyle and conditioned hair, hair drying and pigmentation care.

II. How to use :

A. Before trial run, open the package and check if any components loosened during transportation. If so, please fasten them before trial.

B. Connect to electricity. Turn the time switch clockwise to set a period between 0 to 60 minutes. Then press power switch and choose any temperature from 0 to 70 degree.

C. In order to keep safe, please disconnect the power after use.

III. Cautions :

1. When you install the pipe, you should hold the tip of pipe by hands,

and then adjust the required height.

2. Avoid the appliance working in a condition of sunshine, high temperature and humidity.
3. Avoid the appliance close to the inflammable items.
4. Every time after use, turn off the power switch firstly, and then unplug the power cord.
5. If you find the unit failure or the power cord failure, please repair the unit by manufactory or professional electrician.
6. The user must use the appliance in a correct way according to the instruction. Our company will not take a responsibility for the unit failure or cause other problem if the client uses the appliance out of the intrusions.

WARNING:

1. This machine is not suit for the person who corporeity weakness,

recation slow or impediment pneuma(include children)use,unless it guide by the person who had safe responsibility and safe use.

2. The children should be supervise that make sure they not play the machine.

3. Operation Instruction of Temperature Setting: Turn on the machine to warm-up in advance of 10 minutes, and adjust the knob of temperature control to temperature setting 6. After finish warm-up, the hairdresser should test if the temperature is suitable for user by hand in the dryer hood .If the temperature is not suitable,the hairdresser should keep on adjusting the temperature knob to the proper temperature setting before start hair drying for the customer (the temperature goes up when the knob be turned in the clockwise direction, and also the temperature goes down when the knob be turned in the opposite direction).

Note:

1. To adjust the temperature, please adjust 0.5 marks as the operation standard every time.

2. After finish temperature adjusting, it has to wait 3 minutes before test the temperature in the dryer hood by hand.

As everyone has different sensitivity for the heat on the hand and head, please check if the temperature is over heat when the user's head come in the dryer hood. The hairdresser must let the customers know that..

The time for keep on drying hair should be no more than 15 minutes in order that not hurt the skin.

Setting Level and Temperature Diagram

Note:

1. The data on above diagram of temperature adjusting is for reference only. Since every item has a little difference, it can not be the standard data.
2. As the specialty of the item, the temperature in the dryer hood is not uniform in anywhere, and the date on above diagram is tested in the same place by manufactory.

Technical data:

Volt:220~240V

or

Volt:110~130V

Frequency:50~60Hz

Frequency:50~60Hz

Power:980W

Power:880W

This
all suit for

Setting Level	Temperature Range
4	38~45°C
5	46~52°C
6	53~61°C
7	60~67°C
8	68~73°C

Attention:
instruction
above

electrical appliance description, the products must subject by electric
nameplate..