

Accessories

- Operation manual (this manual)
- Rubber ring
- Installation manual
- Step (with adjuster)
- Flange nut (M6) 3 pcs.

Name of Components

■ Main Unit

