This is the adjustable screw next to the little red light. These wires are installed to the side of some units, or they are taped along the inside of the base.