

#### FORMULATED FOR: BEAUTY SHOP • BARBER SHOP • PET SALON • ANIMAL HOSPITAL Meets AOAC germicidal snrav products test standards for hospital disinfectants.

ns Adac germicidal spray products lest standards for nospital disinfectant.

## HK-V-UIUE **CLIPPER** EASE SPRAY DISINFECTANT/LUBRICANT

For use by hair stylists, barbers, animal groomers and veterinarians. **DISINFECTS AND LUBRICATES HAIR CLIPPERS:** Acts as a virucide, fungicide, bactericide and tuberculocide. Leaves a light lubricating film on clipper blades that reduces the discuss or the action of the discussion of the discussion.

that reduces friction, smooths the clipping action and prolongs the effective life of the blade. COLS HAR CLIPPERS: Turn the clipper off occasionally during use to spray the blade and teeth. The lubricating aerosol sprays away hair, dandruff and dust particles, and cools the metal.

# HAZARDS TO HUMANS AND DOMESTIC ANIMALS KEEP OUT OF REACH OF CHILDREN

Causes eye irritation. Do not get in eyes. Avoid contact with skin. Prolonged or frequently repeated skin contact may cause allergic reactions in some individuals. Avoid contamination of foodstuff. FIRST AID

IF IN EYES: Hold eye open and rinse slowly and gently with water for 15-20 minutes. Remove contact lens, if present, after the first 5 minutes, then continue rinsing eye. Call a poison control center or doctor for treatment advice.

IF INHALED: Move person to fresh air. If person is not breathing, call 911 or an ambulance, then give artificial respiration, preferably mouth-to-mouth, if possible. Call a poison control center or doctor for further treatment advice.

Have the product container or label with you when calling a poison control center or doctor, or going for treatment. ATTENTION: This product contains o-phenylohenol, a chemical known to the

ATTENTION: This product contains o-phenylphenol, a chemical known to the State of California to cause cancer in accordance to Proposition 65 (State of California Safe Drinking Water and Toxic Enforcement Act of 1986).

#### PHYSICAL OR CHEMICAL HAZARDS EXTREMELY FLAMMABLE. Contents under pressure. Do not use or store near

heat or open flame. DO NOT PUNCTURE OR INCINERATE CONTAINER. Exposure to temperatures above 130°F may cause bursting. DIRECTIONS FOR USE

It is a violation of Federal law to use this product in a manner inconsistent with its labeling.

This product is not to be used as a terminal sterilart/high-level disinfectant on any surface or instrument that (1) is introduced directly into the human body, either into or in contact with the bloodsterman rommally sterilar easo the body, or (2) contacts intact mucous: membranes but which does not ordinarily penetrate the blood barrier or otherwise enter normally sterilar eares of the body. This product may be used to preclean or decontaminate critical or semi-critical medical devices prior to sterilization or high-level disinfection. Klils "HIV-1 (Alos VIRGS) on orecleaned environmental surfaces/objects previously

Klits \*HN-1 (ADS VRRIS) on precleaned environmental surfaces/objects previously solide with bload and body fluids in health care settings or other settings in which there is an expected likelihood of soling of inanimate surfaces/objects with bload or body fluids and in which the surfaces/objects likely to be solied with bload or body fluids can be associated with the potential for transmission of HIV.



### SPECIAL INSTRUCTIONS FOR CLEANING AND DECONTAMINATION AGAINST HIV OF SURFACES/OBJECTS SOILED WITH BLOOD AND BODY FLUIDS PERSONAL PROTECTION: When handling items soiled with blood or body

fluids, use appropriate barrier protection such as disposable latex gloves, gowns, masks and eye coverings.

CLEANING PROCEDURE: Blood and other body fluids must be thoroughly cleaned from surfaces and objects before application of this disinfectant. DISPOSAL OF INFECTIOUS MATERIALS: Blood and other body fluids must be autoclaved and disposed of according to Federal, state and local regulations for infectious waste disposal.

CONTACT TIME: Leave surface wet for 10 minutes.

After surface is cleaned, hold can upright and spray 6 to 8 inches from surface to be treated until surface becomes wet. Allow spray to dry without wiping or allow spray to contact treated surface for a minimum of 10 minutes prior to wiping.

FOR DISINFECTION OF INANIMATE SUBFACES: This disinfectant spray is an effective germicidal that kills Staphylococcus aureus, Salmonella enterica, Pseudomonas aeruginosa, Streptococcus pyogenes, Mycobacterium bovis (BCG) and Vancomycin Resistant Enterococcus faecalis (VRE).

It also kills viruses and fungi on hard, nonporous inanimate surfaces. \*Viruses: Influenza A/(HON1) ATCC VR-95, Influenza B/(H,N\_)(ARUP), Herpes Simplex Type 1 and Herpes Simplex Type 2. Fungi: Trichophyton mentagroohvtes (athlete's foot).

This product has demonstrated effectiveness against Influenza A (HON1) and is expected to inactivate all influenza A viruses including Pandemic 2009 H1N1 (formerly called swine flu).

DIRECTIONS FOR DISINFECTION OF HAIR CLIPPERS: After each use, clean clipper blades to remove hair and other organic soil. With clipper turned off, hold lispenser upright 6 to 8 inches from blades. Spray teeth of clipper blades until wet. Keep surface wet for 10 minutes. Allow to air dry.

#### Between full applications, spray clipper to cool blades and blow away stray hairs. Use regularly to keep blades lubricated. DO NOT USE ON POLISHED WOOD FURNITURE OR RAYON FABRICS.

STORAGE: Store in a cool, dry area away from heat or open flame. Do not contaminate water, food or feed by the use, storage or disposal of this product

DISPOSAL: DO NOT PUNCTURE OR INCINERATE! If empty: Place in trash or offer for recycling if available. If partly filled: Call your local solid waste agency for disposal instructions.

THE USER OF THIS PRODUCT ASSUMES ALL RISKS OF USE, STORAGE AND HANDLING NOT IN ACCORDANCE WITH ITS DIRECTIONS AND CAUTIONS.

WILLIAG

COMPANY

1540 St. Clair Ave.

St. Paul, MN 55105 651-698-0726

800-874-2651 (U.S. and Canada)

FAX 651-698-4048

wmmarvvco.com

Distributed by:



�-|||

ဖ